


The COMPLETE solution to water in fuel; from the official UK agent!







SMALL BOATS

 $\checkmark$ 

## **FINGER**

For tanks up to 150 litres with openings between 3.8cm and 9cm. Size: 20cm x 4cm Absorbs up to 200ml



## **SNAKE**

For tanks up to 500 litres with openings between 3.8cm and 9cm. Size: 50cm x 4cm Absorbs up to 500ml



For tanks up to 10,000 litres with openings from 9cm to 20cm. Size: 150cm x 9cm Absorbs up to 4 litres



## **MEDIUM CANVAS**

For tanks with a capacity of 500-5000 litres with access of at least 12cm. Size: 35cm x 27cm Absorbs up to 2.5 litres



## LARGE CANVAS

For tanks with a capacity of 5000-10,000 litres with access of at least 16cm. Size: 70cm x 27cm Absorbs up to 4.5 litres





IBC

















Multiple Anaconda absorbers may be used to remove water quicker, providing they can be removed individually.





